



## MIRROR TO DRESSER MOUNTING INSTRUCTIONS

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Bed Box	1	Mounting Frame	

### Hardware List and Verification

Quantity	Description	QC Check
4	1 5/8" Screws	
7	1" Screws	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

### ASSEMBLY INSTRUCTIONS:

- 1) ATTACH FRAME TO BACK OF DRESSER USING THE 4 - 1 5/8" SCREWS.
- 2) ATTACH MIRROR TO FRAME USING THE 7 - 1" SCREWS.

