

Add Glides to Bed feet

Lift a bed foot off the floor and tap a plastic glide into the bottom with a mallet or hammer and gently into place.

Adding the glides allows the bed to have the right amount of clearance above the storage unit below.

