



## CANAAN BENCH ASSEMBLY

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Table Box	2	Legs	
Table Box	1	Stretcher	

### Hardware List and Verification

Quantity	Description	QC Check
4	2" Lag Bolts	
4	Black Lag Bolts	
8	Flat Washers	
5 (1 Spare)	7/8" Flat Faced Plugs	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

**ATTENTION**  **Do Not Assemble with Power Tools**

### ASSEMBLY INSTRUCTIONS:

- 1) **LOOSELY** ATTACH THE STRETCHER TO BOTH LEGS USING THE **4 - 2" LAG BOLTS** THROUGH THE HOLES IN CENTER OF EACH LEG. MAKE CERTAIN THE COUNTERSUNK (WIDER END OF HOLE) SIDE OF EACH LEG IS FACING OUT. THIS COMPLETES THE BASE ASSEMBLY.
- 2) TURN THE BENCH TOP UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 3) TURN THE BASE ASSEMBLY UPSIDE DOWN AND ALIGN THE HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE BENCH TOP.
- 4) FIRMLY ATTACH THE BASE USING THE **8 - BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE BENCH TOP.**
- 5) FINISH TIGHTENING THE STRETCHER LAG BOLTS INTO PLACE.
- 6) PRESS PLUGS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF PLUGS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE PLUG AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 7) CAREFULLY TURN BENCH UPRIGHT.

