



## SHERWOOD BENCH ASSEMBLY

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Table Box	2	Uprights	
Table Box	1	Stretcher	
Table Box	2	Stretcher End Caps	

### Hardware List and Verification

Quantity	Description	QC Check
4	2" Lag Bolts	
12	Black Lag Bolts	
16	Flat Washers	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

**ATTENTION**  **Do Not Assemble with Power Tools**

### ASSEMBLY INSTRUCTIONS:

- 1) LOOSELY ATTACH THE STRETCHER TO BOTH LEGS USING THE HOLES IN EACH LEG WITH THE 4 - 2" LAG BOLTS. MAKE CERTAIN THE COUNTERSUNK (WIDER END OF HOLE) SIDE OF EACH LEG IS FACING OUT.**
- 2) TURN THE BENCH TOP UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.**
- 3) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE BENCH TOP. ATTACH THEM WITH THE BLACK LAG BOLTS. IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE BENCH TOP.**
- 4) FINISH TIGHTENING ALL LAGS INTO PLACE.**
- 5) PRESS STRETCHER END CAPS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF END CAPS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE END CAP AND GENTLY TAP INTO PLACE WITH A HAMMER.**
- 6) CAREFULLY TURN BENCH UPRIGHT.**

