



## NEW TRADITIONS LAMP PEDESTAL TABLE ASSEMBLY

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	1	"X" Shaped Pedestal	
Base Box	2	Notched Top Straps	
Base Box	2	Notched Bottom Feet	

### Hardware List and Verification

Quantity	Description	QC Check
4	Black Lag Bolts	
4	2" Lag Bolts	
4	3 1/2" Lag Bolts	
12	Flat Washers	
4 (threaded into Bottom Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

<b>ATTENTION</b>  <b>Do Not Assemble with Power Tools</b>
--

### ASSEMBLY INSTRUCTIONS:

- 1) CROSS THE TOP STRAPS TO FORM A "PLUS" SIGN BY INTERSECTING THE NOTCHES TOGETHER.
- 2) ALIGN THE CROSSED TOP STRAPS WITH THE PRE-DRILLED HOLES ON ONE END OF THE "+" SHAPED PEDESTAL (IT DOESN'T MATTER WHICH END). USE 4 - 2" LAG BOLTS TO LOOSELY ATTACH THE TOP STRAPS. BE SURE THAT THE UNFINISHED SIDE OF THE TOP STRAPS FACES AWAY FROM THE PEDESTAL.
- 3) INTERSECT AND LOOSELY ATTACH THE NOTCHED BOTTOM FEET WITH THE 4 - 3 1/2" LAG BOLTS. MAKE SURE THAT THE LEVELERS ON THE BOTTOM FEET ARE FACING AWAY FROM THE PEDESTAL. THIS COMPLETES THE BASE ASSEMBLY.
- 4) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 5) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE. ATTACH THEM WITH THE BLACK LAG BOLTS. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 6) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 7) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

