



## SOLID – BENTON BASE ASSEMBLY

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Morgan Box	1	Base Assembly	

### Hardware List and Verification

Quantity	Description	QC Check
4	Black Lag Bolts	
4	Flat Washers	
4 (Threaded into Bottom Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

**ATTENTION**  **Do Not Assemble with Power Tools**

### ASSEMBLY INSTRUCTIONS:

- 1) PLACE THE TABLE FACE DOWN ON A SOFT NON ABRASIVE SURFACE.
- 2) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE TABLE.
- 3) USE THE **BLACK LAG BOLTS** TO ATTACH THE TOP STRAPS TO THE TABLE. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 4) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

