



SOLID – BURKE TABLE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	2	Legs	
Base Box	2	Top Straps	
Base Box	2	Bottom Feet	
Table Box	1	Stretcher	

Hardware List and Verification

Quantity	Description	QC Check
12	2" Lag Bolts	
4	Black Lag Bolts	
16	Flat Washers	
4 (threaded into Bottom Feet)	Levelers	
5 (1 Spare)	3/4" Button Plugs	

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  Do Not Assemble with Power Tools
--

ASSEMBLY INSTRUCTIONS:

- 1) **LOOSELY** ATTACH THE TOP STRAPS TO THE **NARROW END** OF EACH LEG WITH **4 - 2" LAG BOLTS**.
- 2) USE **4 - 2" LAG BOLTS** TO ATTACH THE BOTTOM FEET TO THE **WIDE END** OF THE LEG. THE FEET SHOULD CURVE TOWARDS THE COUNTERSUNK SIDE OF THE LEG (SEE DRAWING BELOW), BUT ARE REVERSABLE IF DESIRED.
- 3) **LOOSELY** ATTACH THE STRETCHER WITH THE OTHER **4 - 2" LAG BOLTS** TO BOTH LEGS. BE SURE THAT THE COUNTERSINK (WIDER END OF THE HOLE) SIDE FACES OUTWARD. THIS COMPLETES THE BASE ASSEMBLY.
- 4) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 5) ALIGN THE HOLES IN THE TOP STRAPS WITH THE HOLES IN THE BOTTOM OF THE TABLE. ATTACH THE BASE USING THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 6) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 7) PRESS PLUGS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF PLUGS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE PLUG AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 8) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

