

SOLID - CANAAN TRESTLE TABLE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Table Box	2	Legs	
Table Box	1	Stretcher	

Hardware List and Verification

Quantity	Description	QC Check
4	2" Lag Bolts	
8	Black Lag Bolts	
12	Flat Washers	
5 (1 Spare)	7/8" Flat Faced Plugs	

QUALITY CONTROL CHECK PERFORMED BY:



ASSEMBLY INSTRUCTIONS:

- 1) LOOSELY ATTACH THE STRETCHER TO BOTH LEGS USING THE 4 2" LAG BOLTS THROUGH THE HOLES IN CENTER OF EACH LEG. MAKE CERTAIN THE COUNTERSUNK (WIDER END OF HOLE) SIDE OF EACH LEG IS FACING OUT. THIS COMPLETES THE BASE ASSEMBLY.
- 2) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 3) TURN THE BASE ASSEMBLY UPSIDE DOWN AND ALIGN THE HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE TOP.
- 4) ATTACH THE BASE USING THE 8 BLACK LAG BOLTS. IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.
- 5) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 6) PRESS PLUGS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF PLUGS CAN NOT BE SECURED BY HAND, USE A RUBBER MALLET OR FOLD A SOFT CLOTH OVER THE PLUG AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 7) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

