



SOLID – DUNCAN-PHYFE SINGLE PEDESTAL TABLE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	1	Round Column	
Base Box	2	Notched Top Straps	
Base Box	4	Feet	

Hardware List and Verification

Quantity	Description	QC Check
4	2" Lag Bolts	
4	Black Lag Bolts	
8	5/16" Nuts	
16	Flat Washers	
4 (threaded into Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  **Do Not Assemble with Power Tools**

ASSEMBLY INSTRUCTIONS:

- 1) CROSS THE TOP STRAPS TO FORM A “PLUS” SIGN BY INTERSECTING THE NOTCHES TOGETHER.
- 2) ALIGN THE CROSSED TOP STRAPS WITH THE HOLES IN THE **PRE-DRILLED END** OF THE COLUMN. USE **4 - 2” LAG BOLTS** TO **LOOSELY** ATTACH THE TOP STRAPS. BE SURE THAT THE UNFINISHED SIDE OF THE TOP STRAPS FACES AWAY FROM THE COLUMN.
- 3) EACH FOOT HAS 2 MACHINED BOLTS ATTACHED TO IT. PLACE THE BOLTS IN THE HOLES LOCATED ON THE BOTTOM SIDES OF THE COLUMN.
- 4) USE THE **8 - 5/16” NUTS AND WASHERS** TO SECURE THE FEET TO THE COLUMN. THIS COMPLETES THE BASE ASSEMBLY.
- 5) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 6) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE. ATTACH THEM WITH THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2” LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 7) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 8) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

