



## SOLID – GRAND ISLE TRESTLE TABLE ASSEMBLY

### Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	2	Legs	
Base Box	1	Stretcher	
Base Box	2	Bottom Foot	
Base Box	2	Top Straps	

### Hardware List and Verification

Quantity	Description	QC Check
6	2" Lag Bolts	
4	3" Lag Bolts	
6	Black Lag Bolts	
16	Flat Washers	
6 (threaded into Bottom Feet and stretcher)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

<b>ATTENTION</b>  <b>Do Not Assemble with Power Tools</b>
--

### ASSEMBLY INSTRUCTIONS:

- 1) LOOSELY ATTACH THE BOTTOM FEET TO THE STRETCHER BY INTERSECTING THE NOTCHES IN AN "I" FORMATION. USE 2 - 2" LAG BOLTS TO ATTACH THE PIECES TOGETHER.**
- 2) LOOSELY ATTACH 2 LEGS TO EACH BOTTOM FOOT USING THE 4 - 3" LAG BOLTS. MAKE SURE THAT THE NOTCHES ARE FACING THE BOTTOM FOOT BEFORE USING LAG BOLTS.**
- 3) LOOSELY ATTACH A TOP STRAP ON THE TOP OF EACH PAIR OF LEGS BY ALIGNING THE HOLES ON THE TOP STRAP WITH THE PRE-DRILLED HOLES IN EACH LEG. ATTACH THE TOP STRAPS USING THE OTHER 4 - 2" LAG BOLTS. THIS COMPLETES THE BASE ASSEMBLY.**
- 4) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.**
- 5) TURN THE BASE ASSEMBLY UPSIDE DOWN AND ALIGN THE OUTER HOLES OF THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE TOP.**
- 6) ATTACH THE BASE USING THE BLACK LAG BOLTS. IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 7) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.**
- 8) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.**

