



SOLID – NEW TRADITIONS TRESTLE TABLE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	2	Leg Assemblies	
Base Box	2	Top Straps	
Base Box	2	Bottom Feet	
Table Box	3	Stretchers	

Hardware List and Verification

Quantity	Description	QC Check
4	Black Lag Bolts	
20	2" Lag Bolts	
24	Flat Washers	
14 (2 Spare)	3/4" Button Plugs	
4 (threaded into Bottom Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  Do Not Assemble with Power Tools
--

ASSEMBLY INSTRUCTIONS:

- 1) USE 4 - 2" LAG BOLTS TO LOOSELY ATTACH THE BOTTOM FEET TO THE BOTTOM OF EACH LEG ASSEMBLY. SEE THE DRAWING TO CLARIFY TOP AND BOTTOM.
- 2) USE 4 - 2" LAG BOLTS TO LOOSELY ATTACH THE TOP STRAPS TO THE TOP THE LEG ASSEMBLIES.
- 3) STAND BOTH LEG ENDS PARALLEL TO EACH OTHER WITH THE COUNTERSUNK (WIDE END OF THE HOLE) SIDE FACING OUTWARD.
- 4) USE 12 - 2" LAG BOLTS TO LOOSELY ATTACH THE STRETCHERS (WIDE ONE ON THE BOTTOM AND TWO NARROW ONES ON THE TOP) TO THE LEGS (SEE DRAWING BELOW). THIS COMPLETES THE BASE ASSEMBLY.
- 5) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 6) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE. ATTACH THEM WITH THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 7) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 8) PRESS PLUGS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF PLUGS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE PLUG AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 9) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

