



ROXBURY TRESTLE BASE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Base Box	2	X-Leg Assemblies	
Table Box	2	3" Wide Stretchers	

Hardware List and Verification

Quantity	Description	QC Check
8	2" Lag Bolts	
12	5/16" Flat Washers	
4	Black Lag Bolts	
4 (Threaded into Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  **Do Not Assemble with Power Tools**

ASSEMBLY INSTRUCTIONS:

- 1) PLACE THE TABLE UPSIDE DOWN ON A SOFT NON ABRASIVE SURFACE.
- 2) LINE UP THE FOUR HOLES IN EACH X-LEG ASSEMBLY TOP, WITH THE FOUR HOLES IN THE BOTTOM OF EACH END OF THE TABLE TOP. **LOOSELY ATTACH THE X-LEG ASSEMBLIES USING THE BLACK LAG BOLTS. IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**

NOTE: X-LEG ASSEMBLIES ARE MADE TO FIT ONE END OF THE TABLE. SWITCH ENDS IF NECESSARY TO MAKE CERTAIN OF PROPER ALIGNMENT. IF ASSEMBLIES ARE ATTACHED TO THE INCORRECT ENDS, THE STRETCHERS MAY NOT FIT CORRECTLY.

- 3) ALIGN THE 4 HOLES IN EACH STRETCHER TO THE 4 HOLES LOCATED ON THE ENDS OF EACH X-LEG ASSEMBLY. (REFER TO DIAGRAM BELOW FOR PLACEMENT). MAKE CERTAIN THERE IS CORRECT HOLE ALIGNMENT BEFORE TIGHTENING COMPLETELY. LEAVING THE LAG BOLTS LOOSE IN STEP 2 WILL ALLOW FOR SOME ADJUSTMENT ROOM TO INSURE A PROPER FIT. ATTACH THE STRETCHERS USING THE 2" LAG BOLTS. TIGHTEN COMPLETELY.

- 4) FINISH TIGHTENING ALL LAG BOLTS.

