



SOLID – SHERWOOD TRESTLE ASSEMBLY

Base Part Location and Verification

Location	Quantity	Description	QC Check
Table Box	2	Uprights	
Table Box	1	Stretcher	
Table Box	2	Stretcher End Caps	

Hardware List and Verification

Quantity	Description	QC Check
4	2" Lag Bolts	
12	Black Lag Bolts	
16	Flat Washers	
4 (threaded into Bottom Feet)	Levelers	

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  **Do Not Assemble with Power Tools**

ASSEMBLY INSTRUCTIONS:

- 1) **LOOSELY** ATTACH THE STRETCHER TO BOTH LEGS USING THE HOLES IN EACH LEG WITH THE **4 - 2" LAG BOLTS**. MAKE CERTAIN THE COUNTERSUNK (WIDER END OF HOLE) SIDE OF EACH LEG IS FACING OUT.
- 2) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 3) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE. ATTACH THEM WITH THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 5) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 6) PRESS STRETCHER END CAPS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF END CAPS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE END CAP AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 7) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

