



SOLID – THREE-LEG TRESTLE TABLE ASSEMBLY

Base Part Location and Verification

| Location | Quantity | Description | QC Check |
|-----------|----------|------------------|----------|
| Base Box | 2 | 5" Wide Legs | |
| Base Box | 4 | 3 1/4" Wide Legs | |
| Base Box | 2 | Top Straps | |
| Base Box | 2 | Bottom Feet | |
| Table Box | 1 | Stretcher | |

Hardware List and Verification

| Quantity | Description | QC Check |
|-------------------------------|-------------------|----------|
| 28 | 2" Lag Bolts | |
| 4 | Black Lag Bolts | |
| 32 | Flat Washers | |
| 4 (threaded into Bottom Feet) | Levelers | |
| 5 (1 Spare) | 3/4" Button Plugs | |

QUALITY CONTROL CHECK PERFORMED BY: _____

ATTENTION  **Do Not Assemble with Power Tools**

ASSEMBLY INSTRUCTIONS:

- 1) **LOOSELY** ATTACH ONE END OF EACH LEG TO THE TOP STRAPS, 3 LEGS PER SIDE (ONE 5" WIDE LEG IN THE CENTER AND A 3 1/4" LEG ON EITHER SIDE) USING **12 - 2" LAG BOLTS**. IT DOESN'T MATTER WHICH END OF THE LEG IS ATTACHED.
- 2) **LOOSELY** ATTACH THE BOTTOM FEET IN THE SAME MANNER AS STEP 1.
- 3) USE THE OTHER **4 - 2" LAG BOLTS** TO **LOOSELY** ATTACH THE STRETCHER TO BOTH 5" WIDE CENTER LEGS. BE CERTAIN THAT THE COUNTERSINK (WIDER END OF THE HOLE) SIDE OF THE LEG IS FACING OUTWARD. THIS COMPLETES THE BASE ASSEMBLY.
- 4) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 5) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE HOLES IN THE TABLE. ATTACH THE BASE USING THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2" LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 6) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 7) PRESS PLUGS INTO PLACE OVER THE STRETCHER LAG BOLTS. IF PLUGS CAN NOT BE SECURED BY HAND, USE A RUBBER Mallet OR FOLD A SOFT CLOTH OVER THE PLUG AND **GENTLY** TAP INTO PLACE WITH A HAMMER.
- 8) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

