



## SOLID – PEACHAM SINGLE PEDESTAL BASE ASSEMBLY

### Base Part Location and Verification

| Location | Quantity | Description        | QC Check |
|----------|----------|--------------------|----------|
| Base Box | 1        | Column             |          |
| Base Box | 2        | Notched Top Straps |          |
| Base Box | 4        | Feet               |          |

### Hardware List and Verification

| Quantity               | Description     | QC Check |
|------------------------|-----------------|----------|
| 4                      | Black Lag Bolts |          |
| 4                      | 2" Lag Bolts    |          |
| 8                      | 5/16" Nuts      |          |
| 16                     | Flat Washers    |          |
| 4 (threaded into Feet) | Levelers        |          |

QUALITY CONTROL CHECK PERFORMED BY: \_\_\_\_\_

**ATTENTION**  **Do Not Assemble with Power Tools**

### ASSEMBLY INSTRUCTIONS:

- 1) CROSS THE TOP STRAPS TO FORM A “PLUS” SIGN BY INTERSECTING THE NOTCHES TOGETHER.
- 2) ALIGN THE CROSSED TOP STRAPS WITH THE HOLES IN THE **DRILLED (NARROW) END** OF THE COLUMN. USE 4 - 2” LAG BOLTS TO LOOSELY ATTACH THE TOP STRAPS. BE SURE THAT THE UNFINISHED SIDE OF THE TOP STRAPS FACES AWAY FROM THE COLUMN.
- 3) EACH FOOT HAS 2 MACHINED BOLTS ATTACHED TO IT. PLACE THE BOLTS IN THE HOLES LOCATED ON THE BOTTOM SIDES OF THE COLUMN.
- 4) USE THE 8 - 5/16” NUTS AND WASHERS TO SECURE THE FEET TO THE COLUMN. THIS COMPLETES THE BASE ASSEMBLY.
- 5) TURN THE TABLE UPSIDE DOWN AND PLACE ON A SOFT, NON-ABRASIVE SURFACE.
- 6) ALIGN THE OUTERMOST HOLES IN THE TOP STRAPS WITH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TABLE. ATTACH THEM WITH THE **BLACK LAG BOLTS**. **IMPORTANT: BE CERTAIN TO USE THE BLACK LAG BOLTS, AS THE LONGER 2” LAG BOLTS MAY ACTUALLY GO THROUGH THE TABLE TOP.**
- 7) FINISH TIGHTENING ALL LAG BOLTS INTO PLACE.
- 8) CAREFULLY TURN TABLE UPRIGHT. ADJUST LEVELERS AS NEEDED.

